# MAKE THE MOST OUT OF YOUR SEASONAL SHUTDOWN.

PLAN AHEAD.






From replacement parts and consumables to field and metallurgical services, Nitrex has you covered.

nitrex.com


# TIME TO CHECK THE CONDITION OF THESE PARTS

### REPLACE IF NEEDED



### → HOT ZONES

- Heating elements
- Element connectors
- Element hanger assembly
- Element supports




### → POWER FEED THRUS

- Water cooled cables
- Copper
- PFT teflon



### → THERMOCOUPLES

- Control T/C
- Thermocouples
- Thermocouple jacks



### → PUMPS & MOTORS

- Holding pumps
- Roughing pumps
- Furnace motors & fans
- Heat exchangers

NITREX nitrex.com

## TIME TO CHECK THE CONDITION OF THESE PARTS

### REPLACE IF NEEDED




#### → CONTROLLER & WATER SYSTEM

- Control panels
- Water systems

#### → MISCELLANEOUS ITEMS

- Furnace seals
- Fuses
- Grafoil washers
- Graphite nuts
- Graphite-threaded rods
- Insulator washers
- Insulators
- Lip seals
- Moly nuts
- Moly-threaded studs
- Pressure transducers
- Relays
- Vacuum gauge tubes
- Vacuum grease



# YOUR NITREX VACUUM FURNACE MAINTENANCE

### **CHECKLIST**

	DAILY	WEEKLY	MONTHLY	6 MONTHS	12 MONTHS
CALIBRATION					
Blank-off pressure at pumps				•	
Vacuum T/Cs			•		
Instrumentation				•	
INSPECTION & CLEANING / REPLACEMENT					
Door O-rings *					•
Belt tension on pumps				•	
Cooling blower motor – Power feed-throughs					•
Cooling blower motor – Main power cables					•
Hot zone – Fiber insulation/hot-face *					
INSPECTION/GREASING					
Door O-rings		•			
Door hinges				•	
Cooling blower motor – Bearing				•	
INSPECTION					
Visual inspection of furnace	•				
Change oil in mechanical pump*				•	
Change vacuum blower oil*					•
Leak rate chamber		•			
Element connections			•		
For 6-Bar or Greater: Heat exchanger unit, cooling motor and power feed - through contacts.				•	
Water flow	•				
Grease cups				•	
OTHER					
Clean diffusion pump and change oil*					•
Clean vacuum valves*					•
Bake-out furnace max-temperature*			•		
Clean chamber interior*				•	
Clean power supply					•
Tighten power supply connections					•
Change holding pump oil*				•	

 $<sup>{}^{\</sup>star}\mathrm{Or}$  as operating conditions dictate.

NITREX nitrex.com



Americas: +1 514 335 7191

Toll Free North America: 1877 335 7191

Europe: +48 32 296 6630

aftermarket@nitrex.com

MASTERING STRENGTH. WORLDWIDE.

nitrex.com